Directory

Basic Information **3**

Brief Introduction *3*

Safety Notice *3*

Cleaning and Maintaining *3*

Before Using **4**

SIM *4*

Phone Unlock *4*

SIM Unlock *4*

Function menu Introduction **4**

Dialer *5*

Messaging *5*

Conversations 5

Drafts 6

Broadcast messages 6

Message settings 6

Media player *6*

Phonebook *7*

Call logs *8*

Calendar *9*

Camcorder *9*

Settings *9*

Duad SIM settings 10

Pen calibration 10

Phone settings 10

Network settings 12

Security settings 12

Notification settings *13*

Call settings 13

Restore factory settings 16
Alarm 16
Image viewer 16
Calculator 16
File manager *17*
Soud record 17
Connectivity 17
Tasks 17
FM radio 18
World clock *18*
SIM toolkit 18
Blutooth 18
Browser *19*
Mobile TV *19*
Movie *19*
Profiles *20*

Basic Information

Brief Introduction

Thank you for choosing ICE MOBILE---SOL II. You can read the manual, a comprehensive understanding of the use of mobile phones and enjoy its perfect functionality and simple method of operation.

SOL II supports two SIM cards function.In addition to basic call functions, but also to provide you with phone book, personalized ring tones, alarm, camera, image viewer, video recorder, video player, audio player,Mobile TV， FM, One Memory Card (T-Flash card), calculator, calendar, torch etc. A variety of practical features to facilitate your work and leisure activities, in addition, SOL II interface with personalized mobile phone design, its perfect functionality to meet your needs.

Our Company reserves without any prior notice the contents of this manual under the right to make changes.

Safety Notice

If your phone is lost or stolen, immediately notify the telecommunications sector, or its outlet, to disable the SIM. This will allow you to take phone calls from other economic loss arising.

To make you more secure use of mobile phones, please take precautionary measures, such as:

- Set up mobile phone SIM card PIN password, PIN password to prevent your SIM is unauthorized use by others.

Cleaning and Maintaining

Do not use the bathroom where high humidity, cell phone, battery and charger, the same should also avoid the rain.

Use a soft, dry cloth to clean the phone, battery and charger.

Dirt outlet will lead to poor contact, power-down, which does not charge, regular cleaning.

Before Using

SIM

Before using your phone you must insert a valid SIM (Subscriber Identity Module) card. SIM card provide by the network provider.

Warning: Be sure to remove the SIM phone off before. There is absolutely prohibited in the case of an external power supply connected to insert or remove the SIM, or SIM card and mobile phone may be damaged**.**

Phone Unlock

In order to prevent illegal use, your phone can set the phone lock password protected. Use this function, you must enter the phone lock password so that you can unlock the phone into the normal use state.

Enter the phone lock password, Click the **LSK** to confirm. For example, if the phone lock password is set to 1122, then the following input: **1122 OK**

SIM Unlock

In order to prevent illegal use of your SIM with PIN (Personal Identification Number) password encryption protection. Use this function, if you have set the PIN password protection, every time you must enter the PIN password at boot time, so that you can unlock the SIM card and phone to normal use.

Enter the PIN password, press the **LSK** to confirm. For example, if the PIN is set to 1234, then the following input: **1234 OK**

If three consecutive incorrect, your SIM will be network locked, the phone will ask for PUK password.

Function menu Introduction

Dialer

Into the dialer menu，you can enter any number you want to call, you can click the bottom right corner of this icon of the phone into the phone book menu，Click the * key, you can enter“ *”、“+”“ W”、“p” characters and long press the “ # ” key to switch to silent mode，when you enter number，click options ，there are there options，Call、save to phonebook and dialer search.

Messaging

Write Text message

Make sure that the information in writing before the message center number is set correctly.

Into the message menu，Click the blank space, you can open the virtual keyboard to enter characters，click the “TO” Icon，can into phonebook menu，and Click the input box to enter the number interface，When you add a number and enter the character, click on the bottom line information to send icon to send a message。

Click the left soft-key option, the following options ：

Send After editing the information, select the operation, enter the number manually, or add records from the phonebook, you can send themessage

Add recipient Add number from phonebook.

Insert symbol Add symbol from this menu

Input method Sample method can choose

Input method setting Multi language setting and English setting

Insert template Ten kinds of template can choose

Advanced Insert number and insert name

Save SMS save to drafs.

Conversations

Into the conversations menu, Information list screen, click on the information sent icon reply, click to dial icon to call the sender

number, click the Delete icon to delete information, and click options can do the following

OPen Access to the information dialog box interface
Reply Send SMS to the sender.
Call Make a call to the sender.
Forward Send the message to other people.
Delete Delete the message.
Delete all Delete all messages.
Save to Phonebook Save the number to phonebook.
Delete several Mark several or all to delete

Drafts

Edit the SMS not sended but stored in the draft, the detail features, please refer to "Inbox".

Broadcast messages

Broadcast is a public network operators to send messages. Using the cell broadcast service, you can receive from the network operator information on various topics, such as weather, taxis, hospitals and so on. For information on available topics, please contact your local network provider.
Note: The cell broadcast function needs the network operator support.

Message settings

It has Text message, Multimedia message, Service message and Conversations setting. Users can set SMS/MMS memory status, preferred storage and save sent message or not by themselves.

Media player

Into Media player menu，three are four menu：

Now playing IntoNow playing menu, Click on the full screen icon in full-screen playback, click on the icon to switch one to the next song, click the pause icon to pause, click the Stop icon to stop,click solf key into option list,there are four options:current playlst、go
to library and setting、detail.

All songs Into all songs，click options，have these option，play、Refresh、Add to playlist、delete、send、use、detail.

All videos Into all videos，click options，have these option，play、Refresh、Add to playlist、delete、send、use、detail.

Music playlists Into music playlists menu, click options and select New, Enter any character choose to save,add play list from memory card.

Phonebook

Into the phonebook menu，When the cursor is positioned on any contact, click to dial icon to call, click the information icon to send information, click the Edit icon to edit operation.

Select a record in the phonebook, you can do the following:

-View View the details or edit record.

-Send text message Send SMS to this number.

-Send multimedia message Send multimedia message

-Call Make a call to the number.

-IP dail Make an IP call to the number.

-Edit Can edit and save record.

-Delete Delete the record.

-Copy Copy the current record to Phone/SIM.

-Send business card Send business card through text message、multimedia message and Bluetooth.

-**Add to Blacklist** Add the number to the blacklist

-**Mark several** Mark several number can send text message、business card and delete

-Phonbook settings

-Preferred storage Can be in the SIM1, SIM2, Phone and All to switch, and phonebook list will change accordingly, such as select SIM1, the phonebook list will only show SIM1 records .

-Speed dail Open the speed dial, the dial-up interface, long press the number keys to dial the numbers corresponding to achieve the record.

-My number my number can be edited and sent.

-Extre numbers can be set SIM owner numbers and fixed dialing numbers.
-Memory status View the usag and free Phonebook capacity information.

Call logs

ALL calls

Enter the all call menu, will display the all calls list. Call when the cursor is positioned in any contact, click the dial-up icon, click the information icon to send information, click MMS icon into the MMS editing interface，Select one calls records, click "Options":
-View View the details.
- Call Call the record number.
- Send SMS message Send SMS to record number.
- Save to Phonebook Save the number to the phone or SIM card.
-Add to Blacklist Add the number to the blacklist.
- Edit before call Before the call number can be edited.
- Delete Delete the number
-Delete all Delete all the numbers
-Advanced This menu have call timers、call cost and GPRS counter

Dialed calls

Enter the dialed calls menu to display the current record of outgoing phone list of phone numbers.
Please refer to All calls for details.

Missed calls

Enter the missed calls menu to display the current record has been received mobile phone number list.
Please refer to ALL calls for details.

Received calls

Enter the received calls menu to display the current record of outgoing phone list of phone numbers.

Please refer to all calls for details.

Calendar

Into the calendar menu，click the “option”menu into Options list：

View View task

View all View all tasks

Add event Add task

Delete event delete task

Filter have Local event and select all menu

Jump to date: Can quickly jump to a specified date to a specified date.

Go to today: Switch to the system today, setting the current date.

Go to weekly view View weekly

Start of week Can choose to display the Monday or weekend

Camcorder

The phone includes high-definition camera, you can take pictures anytime, anywhere, and to save the photos to your phone or memory card

Into the camera interface, click the Settings icon in the lower left corner, has the following features：

EV Has “-2.0”、“-1.5”、“-1.0”、“-0.5”、 “0”、“+0.5”、“+1.0”、 “+1.5”、 “+2.0”

Switch to Switch to photo album or Video recorder

Capture mode Has Normal and Continous shot option

Scene mode Has normal and Night option

Image size Has Wallpaper and VGA size

Self-timer Has off、5 secs、10 secs option

White balance Has Auto、Daylight、Tungsten、Fluorescent、Cloudy、Incandescent option

Effects Has Normal、Grayscale、Sepia、Sspia green、Sspia blue、Color invert option

Adv.setting can set the storage location for the phone and memory card

Settings

Duad SIM settings

Seleclt to open or close SIM cards' function. If there are no SIM cards in the card ports, then you can not do operations with the card.

The SIM cards' function will active when you open the SIM card.

Pen calibration

In order to improve click precisely, you can choose this item to calibration screen

Phone settings

Into the phone settings sub-menu, you can make the following settings:

Time and Date

In this menu, you can move the phone time and date settings. The menu consists of three sub-menu:

Set home city: The city a total of 78 international cities by selecting different cities, change the mobile phone area.

Set time/date: Set time and date are set according to the established format and on / off daylight saving function. Phone allows you to set a calendar from 2000 to 2030 between the dates. If daylight saving is set to open, then the phone time to add in the original time of one hour or one hour later.

Set format: Set time and data's form

Update with time zone has on and off option

Schedual power on/off

There are two powered on and two powered off time for you to edit. every time item includes: enable , disable, content and ect. Finish the setting , you must open this item. when time is up, the phone will execute relevance operation.

Language

Phone supports English,Portuguese,Spanish,French for you to select. Set the current language type, then menu and interface refresh for the corresponding language.

Inernational keyboards

Into the international keyboards menu，Has multi language setting and English setting.

Widget manager

Into the widget manager menu， has widget display and widget order Option.

Shortcut manager

Into the shortcut manager menu， Select any menu to open the menu will be displayed in the standby interface，The option to turn off the standby interface will not be displayed.

Encoding

Into the Encoding menu，Four encoding：ASCII、CP1097、CP1098、Windows-1252.

Display

Wallpaper: Into the wallpaper menu，home screen wallpaper and lock screen wallpaper， set in two ways: First, through the navigation system comes with the wallpaper and select; the second is user defined, by browsing the [File manager] photos folder identified as a wallpaper.

Menu page transition: This menu have many kinds of menu page transition can choose

Lock screen image: Has System provided and userdefined option

Screen auto lock： Mobile phones set to set the Auto key lock function, identify lock set into the keyboard interface, you can choose to turn off, respectively (keyboard auto lock function is invalid), 5 sec, 30 sec, 1 min, 5 min, if in idle screen has no any operation, automatically locks the keyboard.

Flight mode

Turn On/Off the Normal or Flight mode. If you select Flight mode, SIM cards' function will not active.

UART settings

You can set it as any SIM card.

Misc. settings

Set the brightness and time . LCD brightness settings are divided into five level.

Network settings

Network selection

New search: Re-search network.

Select Network: Search Network, you can choose from a list of networks you need to network.

Selection mode: Press the left soft key to select automatic or manual mode. Automatic, mobile phone SIM card information is automatically selected according to service provider; manually, choose manually select the network services, mobile phone search to get the current list of service providers for users to select the service provider SIM card type.

Preferences

Preferences, that mobile phone networks in the search process, the preferred provider. Enter the menu will list the current user to customize the priority list of network providers, the left soft key "Options" menu includes the following:

Change priority: The preferred network provider to change the current priority of the selected network.

Delete: Delete the currently selected provider.

Security settings

Into the "Security Settings" menu, you can set the phone's security options, mobile phone or SIM card to avoid unauthorized use.

SIM security settings

PIN lock

SIM card PIN password to lock the completion of your SIM card to prevent unauthorized use.

If the current SIM card lock is closed, select Open to open the SIM card, enter the PIN lock password, the next boot requires that you enter the correct PIN password to enter;

If the current SIM card lock is On, select Off to close the PIN lock protection.

Change PIN: If the current PIN password lock has been activated, you can re-set on the PIN password

Change PIN2: PIN2 old to enter the correct password, you can set on the PIN2 password.

Phone security

Phone lock:

Phone lock password can prevent your mobile phone stolen by others. Select On to open phone lock password to enter the correct password-protected phone lock open, the next boot requires that you enter the correct password to enter the phone lock.

Change password:

Change the phone password, enter the old password and then enter a new password. Phone default password is 1122.

Notification settings

Notification service has messaging、call logs and Downloads setting.

Call settings

Enter the call set up sub-menu, you can make the following settings:

Call waitting

Open this feature, during the call if the new call, the network will

notify you. Specific use with your network provider.

- **Avtivate** lanch the function.
- **Deactivate** Close the function.
- **Query status** Query the function's status.

Call divert

Network Call Transfer service allows you to call a business case in a default transferred to a phone number you specify.

The features include: Divert all voice calls,Divert if unreachable,Divert if no answer, Divert if busy,Divert all data calls.Enter the corresponding Transfer menu, you can do the following:

- **Acitvate** Transfer the current call forwarding setting number.
- **Deactivate** Call transfer prohibited.
- **Query status** Check the satus of this function.

After setup is complete, when, when you do not need call forwarding, you can cancel all diverts to prohibit the use of the above functions.

Call barring

Into the "Call barring" sub-menu, you can set the following call barring any combination to improve security. Some network providers may not provide this service call restrictions, specific use, please contact your network provider. Network provider will provide a four-ban password so that you can enable call restrictions.

Change the password to enter the old call barring password, set new restrictions on the password.

Line switching

In line 1 and line 2 to switch between, choose line 1, can be a normal call, send text messages and so on. Select line2, you can receive a call but not make a call.

Advanced settings

Blacklist

This feature allows you to use in case of do not want to be disturbed, add the number to open the blacklist after blacklist, the number can not dial your phone.
Reject unknown calls can open and off
Reject numbers in blacklist can open and off
The blacklist Number can enter your own can also be joined from the phone book

Auto redial

Through on / off settings, to activate or disable the feature.Turned on and when your phone call after another failed attempt to connect up to redial 10 times. This feature can save you the trouble of repeated calls.

IP dail

Mobile phone support for IP dialing, editing set up to three IP numbers. When you are in the phone book, the selected number and press the OK key to select "Options", select the IP dial-up when the mobile phone before the number that will be activated automatically with the current IP number, and exhaled.
IP number is recorded in the selection of a state, press the LSK to select "option" can be

Activate Select SIM card to activate the function.
Deactivate Select SIM card to deactivate the function.
Eidt Edit the IP number.

Auto redial:

Through on / off settings, to activate or disable the feature.Turned on and when your phone call after another failed attempt to connect up to redial 10 times. This feature can save you the trouble of repeated calls.

Call time reminder:

In this menu can prompt a certain length of time to set up the call, according to the menu function mode in order to select the following tips:

Off Close the function.

Single Enter any number between 1-3000, which arrived at the selected time (seconds) of talk time when prompted.

Periodic Enter any number between 30-60, from the input time (in seconds), the intervals of 1 minute for talk time tips.

Reject by sms

If can not want to answer the call，you can select reject the calls and send the sms

Answer mode

Any key and Anto answer when headset mode two choices for selecting.When you select any key, press any key outside power key and RSK can answer the call.

Restore factory settings

In this menu, enter the phone lock passworde, once determined, the phone automatically reboot the phone after the relevant parameters can be set to return to the case of mobile phone factory. The default password is 1122.

Alarm

Five alarm can be set up (turned off the alarm is still valid.)

Select and edit an alarm clock: Can edit the setting of alarm on / off, Time, Repeat, and Alert type. You can choose to set to repeat: Once, Everyday, Custom.

Image viewer

Select an album sub-menu, you can easily view stored in the camera album picture list, and click the LSK to enter to "Options" to choose the pictures to do the View, Image information, Browse style, Send, Use as, Rename, Delete, Sort by, Delete all files and change Storage operations.

Calculator

Your phone provides you with the basic arithmetic operations can be a function of the calculator, easy simple operation.

Click the right soft key "Clear" can be cleared or the results of the latest input.

Click the right softkey "Back" to exit the calculator

Note: This calculator has limited accuracy and rounding errors will be generated, especially in addition to endless time. When the calculation of range, the display area will use the letter "E" to represent.

File manager

Into the File manager menu, the menu display **Phone** and **Memory card**, the top screen will display all of the current drive storage space, and the free space currently available.

Root directory, select "Phone", Click the left soft key to enter "Options" can be as follows:

- Open open the root directory lists the directories and files.

- Format format the memory card, this action will remove all current flash memory data.

Root directory, select **"Memory Card"**, press the **LSK** to enter **"Options"** can be as follows:

-Open open the root directory lists the directories and files.

-Format format the memory card, this action will remove all current flash memory data.

-Details For more information you can view, such as Name, Total size, Free size.

You can paly the music or video files, view Photo, copy/move/delete files, remame files and so on.

You can send the file through Bluetooth.

Soud record

In the sound recorder interface click "option", it shows the items of record.

New record Start to new record. If you click stop , it will pop up a dialog box to prompt you save it or not. If you click pause, it will suspend recording, and then click continue, it can record again.

List It displays the sound that you recorded and saved in the memory card.

Settings you can set the storage and audio quality of the record.

Connectivity

Into the connectity menu，have data connection SIM and Data account two option settings.

李静 8/14/12 2:34 PM
Comment: 删除，无此功能

李静 8/14/12 2:35 PM
Comment: 改为one

Tasks

Into the tasks menu，click the left soft key add to add task，in the Editing interface，you can edit subject、priority、due time、alarm、repeat、detail、status.

FM radio

Into the FM radio menu，click the list icon into option list

Channel list: Shows FM channel list.

Manual input: Can be their own editors to manually enter the channel frequency, the effective value of 87.5 ~ 108.0

Auto search: Auto search FM channels in the channel list.

Settings: Can modify the Background play, Record format and Audio quality settings. Open the Background play, in the other interface can also play FM.

Record: To record FM.

File list：Display FM radio recording file

World clock

In the world clock interface, users click right or left button can change region and time. Click "option", you can set on or off daylight saving time for foreign city or not. If select on, the present time increase one hour. Otherwise, it displays local time.

SIM toolkit

Into the SIM toolkit menu，Display the relevant information on the SIM card.

Blutooth

Bluetooth

Power: Activate Bluetooth on or off the Bluetooth function.

Visibility: If set as On, other devices can search this Bluetooth device; if set as Off, other devices can not search this Bluetooth device.

My device: Can search for nearby Bluetooth devices.

Search audio device: Free devices to search for near-free decoration, such as Bluetooth headsets.

My name: The Bluetooth device name can be modified.

Advanced Options :

Audio path Set the sound path can be set to stay in the sound and go hands-free cell phone devices. If set to go hands-free device, connected to the phone, the sound will be automatically transferred to the handsfree device.

Storage To receive the file will be automatically transferred to the specified path, the path can be set as phone or memory card.

My address Display device Bluetooth physical address.

Browser

In the internet service interface, it has includes the following items:

Home page Log on homepage, you will find it is a WAP website that you setted. users can set it by themselves.

Bookmarks It has default bookmarks, yahoo. You can go to relevant website conveniencly. Users can add bookmarks by themselves.

Search or input URL Enter the relevant website

Input address You can edit any website you want, but it is effective

Recent pages It records the website that you browsed

Settings It includes following items to users to set: homepage, data account, browser options, preferences settings.

Mobile TV

Your phone provides the functions of television programs. Through the menu interface into the TV player interface, click option to enter the Options menu:

1.play: play to the channels

2.Update: Select the region where the mobile phone is in location,Update the channels

3.Rename:Rename the channels

4.Delet:delet the channels

Movie

This function of the preferred video films source copyed file management Movie file folder of the phone or memory card， Enter this menu, select the memory-chip source,into recently played option

list，select refresh，Movie will display ALL menu，and you can play the movies.

Profiles

Profile including General, Silent, Meeting, Outdoor and My style mode. First, based on the current scene, select a different profile, then you only need a personal profile can be set and activated.

General: General environment.

Silent: For Silent environment.

Meeting: For meeting the environment, to be pre-set (for example: ring mode can be set to vibration).

Outdoor: For outdoor activities, need to pre-set (for example, ring volume can be set to a higher state).

My style: Defined by user.